

How to Reset the Baud Rate on the Unitech HT-630 Handheld After Prolonged Battery Discharge

1. You should charge the handheld for at least 48 hours to charge both the main battery and the backup battery.
2. Press and hold the CMD and ← keys. Press the power button. The unit should wake up and display:

```
<<Start Menu>>  
1. Supervisor  
2. Warm Start  
3. Cold Start
```

3. Press 1 to select Supervisor.
4. The unit will now ask for the password. Enter 630 and press ENT.
5. The following will be displayed:

```
1.DEV 2.TERM  
3.MEM 3.FORM  
5.PWR 6.PWSD  
7.SYS 8.DIAG
```

6. Press ENT to select DEV.
7. Press 3 to select COM1.
8. Press the → key to select a baud rate of 38400. If you go to far keep pressing the key until 38400 reappears.
9. Press ENT until the <<DEVICE CONFIG>> Menu appears again. Do not make any additional changes to the information already selected.
10. Press ESC.
11. Press ESC again. The BIOS message should now be displayed.
12. Long press the CMD button and the familiar RUN menu will be displayed.

You should now be able to transfer your data to and from the handheld. Please remember to charge your handheld at least 2 times overnight each month. Failure to do so will severely shorten your unit's battery life.